

National Guard Products Inc.



1-800-
647-7874

L-CVFM-SS

Installation Instructions

1. Cut out door in accordance with door manufacturers procedure.
2. Install glass & glazing material (sold separately) into lite kit.
3. Position outer frame in door cut out and insert and start all screws before tightening.
4. Tighten screws using a crisscross pattern. Use caution when using power screw driving equipment to avoid stripping the material.
5. Position inner frame and secure to door using the same procedure.

4/05

