



For the complete list of GapGuard Fire Door Accessories, the most up-to-date product information and installation instructions, scan the QR code or visit [ngp.com](http://ngp.com).



# 9220WH

Excessive Clearance Door Bottom, Up to 1 1/2" — 20 Minute

## INSTALLATION INSTRUCTIONS



### Installation Procedure:

1. Measure and cut door bottom and gasketing insert to fit.
2. Crimp or stake metal retainer at both sides and both ends to prevent gasket from migrating.
3. Close door. Hold sweep at

bottom of door. Tap down until contact is made between the sweep and threshold or just above finished floor up to 3/4" as illustrated.

4. Mark screw holes.
5. Drill pilot holes for screws using a 7/64" drill bit.

6. Install with screws provided.
7. Adjust position so sweep does not impede proper closing and latching of door.
8. Install end caps, if desired, as illustrated. (Required in Canada.)

For use on up to 20-minute UL10B, UL10C and CAN/ULC-S104 wood or hollow metal fire doors with bottom of door clearance exceeding 3/4", up to 1 1/2".



POSITIVE PRESSURE TESTED  
MISCELLANEOUS FIRE DOOR  
ACCESSORY  
01.26

**STORAGE AND SHELF LIFE**  
The adhesive on this seal has a shelf life of one year stored at 75°F and 50% relative humidity or less

**Made in USA**

NGP-GAP-9220-PRI-0126-A



MEMPHIS | CARSON CITY

### NATIONAL GUARD PRODUCTS, INC.

**MEMPHIS**  
4985 East Raines Road  
Memphis, TN 38118

**CARSON CITY**  
3689 Arrowhead Drive  
Carson City, NV 89706

**Fax:** (800) 255-7874

**Email:** [info@ngp.com](mailto:info@ngp.com)

**Quotes:** [quotes@ngp.com](mailto:quotes@ngp.com)

**Orders:** [orders@ngp.com](mailto:orders@ngp.com)

**ngp.com**  
**1-800-NGP-RUSH**