INSTALLATION INSTRUCTIONS

# Nylon Brush Perimeter Seal or Door Sweep

1. Remove brush from metal retainer.
2. Cut brush to fit opening, using the cutting section of pliers or diagonal cutters. If bristles are not secure, crimp the end of the metal or use a drop of adhesive to secure the brush.
3. Cut the metal retainer to length.
4. Replace brush in metal retainer.
5. With door closed, position sweep at bottom of door and tap down until contact is made between the sweep and the threshold. Mark screw holes.
6. Drill pilot holes for screws with a 7/64" bit.
7. Install with screws provided.
8. Slightly peen the ends of each retainer to secure the brush from moving.
9. Adjust position so sweep does not impede proper closing and latching of door.

UL CERTIFIED SAFETY US CA R10042

POSITIVE PRESSURE TESTED GASKETING MATERIALS FOR FIRE DOORS FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS RATED UP TO 1½ HOURS. CATEGORY J

MODELS 600, 602, A605, B606, A625, A626 (ONLY): SMOKE AND DRAFT CONTROL GASKETING (CATEGORY H) TESTED TO UL 1784; MEETS REQUIREMENTS OF NFPA 105, IBC FOR USE ON "S" LABEL DOORS.


**ngp.com**
**1-800-NGP-RUSH**

FAX: (800) 255-7874
QUOTES: quotes@ngp.com
ORDERS: orders@ngp.com

**NGP MEMPHIS**
4985 East Raines Road
Memphis, TN 38118

**CARSON CITY**
3689 Arrowhead Drive
Carson City, NV 89706