




# OV634

## Nylon Brush Seals



*Perimeter &  
Door Sweep*



*Door Sweep  
Application only*

*See [ngp.com](http://ngp.com) for  
All Applicable  
Certifications for  
this Product.*



POSITIVE PRESSURE  
TESTED GASKETING  
MATERIALS FOR  
FIRE DOORS FOR  
APPLICATION TO  
HOLLOW-METAL-  
TYPE FIRE DOORS  
RATED UP TO 3  
HOURS AND WOOD-  
TYPE FIRE DOORS  
RATED UP TO  
1½ HOURS.

CATEGORY J & H.

(CATEGORY H  
APPLIES TO  
DOOR SWEEP  
APPLICATIONS  
ONLY)

DOOR SWEEP  
APPLICATION  
IS SMOKE AND  
DRAFT CONTROL  
GASKETING  
(CATEGORY H)  
TESTED TO UL  
1784; MEETS  
REQUIREMENTS OF  
NFPA 105, IBC FOR  
USE ON "S" LABEL  
DOORS.



**[ngp.com](http://ngp.com)**

**1-800-NGP-RUSH**

FAX:

(800) 255-7874

QUOTES:

[quotes@ngp.com](mailto:quotes@ngp.com)


ORDERS:

[orders@ngp.com](mailto:orders@ngp.com)



## INSTALLATION INSTRUCTIONS

### OV634



1. Remove brush from metal retainer.
2. Cut brush to fit opening, using the cutting section of pliers or diagonal cutters. If bristles are not secure, use a drop of adhesive to secure the brush.
3. Cut the metal retainer to length.
4. Replace brush in metal retainer.
5. With door closed, position seal and mark screw holes.
6. Drill pilot holes for screws with a  $\frac{7}{64}$ " bit.
7. Install with screws provided.
8. Slightly peen the bottom end of each retainer to secure the brush from moving.
9. Adjust position so brush is touching against door, but does not impede proper closing and latching of door.

**ngp.com**

**1-800-NGP-RUSH**

FAX: (800) 255-7874

QUOTES: [quotes@ngp.com](mailto:quotes@ngp.com)

ORDERS: [orders@ngp.com](mailto:orders@ngp.com)