



**National Guard
Products, Inc.**

Door Sweeps

Do not install this product to impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to insure the door assembly closes and latches properly, whether or not equipped with a closing device.

Installation Instructions

1. Measure and cut gasketing material to the exact length required for the opening.
2. Locate the door sweep assembly on the bottom of the door. Close door. Tap door seal down until desired contact is made between sweep and threshold.
3. Mark hole locations with a punch or other marking tool.
4. Drill pilot holes for each screw using a 7/64" drill bit.
5. Fasten screws to door through the slots of the door sweep assembly.
6. Adjust as necessary.



UL 10C Positive Pressure Tested Gasketing Material for Fire Doors. Also Classified in accordance with Uniform Building code standard 7-2 Fire Tests of Door Assemblies (1997).



UL10B Gasketing Materials for Fire Doors.
Intended for Application to Listed or Classified Hollow Metal and Steel Covered Composite type fire doors rated up to and including 3 hours and Wood Covered Composite and Wood Core fire doors up to and including 1 1/2 hours.

OK for use on S label doors.